





# ASY WINK 115 LED GE

130710XX 130711XX 130712XX 130713XX 130714XX 130715XX 130716XX 130717XX 130718XX 130719XX 130720XX 130721XX



	The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person		DO NOT TOUCH LED
<b>CHECK DIP-SWITCHES ON DRIVER</b>		<b>PREVENTING ELECTROSTATIC DAMAGE</b>	
	ON OFF 1 2 3 4 5 6		A discharge of static electricity may damage sensitive components. Always be properly grounded when touching leads or circuitry inside the luminaire. Use a wrist strap connected by a ground cord to the housing. Avoid touching the light sources with bare hands.

